

## ENGINE AIR FILTER - AXEAF-12050

HONDA CR-V 1.5L 2017-2021, CIVIC 1.5L 2016-2021

### TOOLS:

No tools required

### STEPS:

Use proper protective gear.

- 1). Loosen wing nut or other fasteners to remove filter cover.
- 2). Remove old air filter.
- 3). Clean filter cover and housing using a shop vacuum.
- 4). Install new air filter. Be sure it is sealed around the perimeter.
- 5). Replace cover and fasten.